

## **SERVICE NOTE**

Date: 08 July 2011

## Object:

- Maintain distance between air filters and upper beam.

## **Aircraft Concerned:**

- All versions of trike LST Skypper 912

## Inspection and action to be taken:

- Check the distance between air filters and upper beam, which should be greater than 1cm (0.4in). In order to keep the air filters pushed back against the engine cover, attach them with two Rilsan clasps (one for each filter). Attach the left filter to the Ø10 tube of the engine mount and the right filter to the engine cover through which you have drilled a Ø5 hole to fit the clasp.





